



Destination Audio

Audio Products That Complement Your Life.™



CS100 / CS100C **COMPACT SPEAKERS**


Installation & Operation Manual

Introduction

Congratulations on your purchase of Destination Audio compact theater speakers! Your speakers are the result of many years of research and development dedicated to producing powerful, high-quality home audio systems. Sophisticated computer modeling and measurement techniques are used extensively in the Destination Audio speaker design process.

This manual contains setup recommendations and specifications for the CS100 & CS100C compact theater speakers. It is highly recommended you thoroughly read through the material contained in this manual before connecting your speakers. This will ensure you have an understanding of how to properly setup, operate and maintain your speakers for optimum performance and maximum enjoyment.

Compact Theater Speakers



CS100 Surround Speaker

CS100C Center Channel Speaker

Break In Period

Allow 18-24 hours of listening time for your speakers to adequately break-in. During this period, the driver suspensions will loosen, the result will be an increase in bass, improved definition, and increased clarity and detail.

Care and Cleaning

To maintain the speaker's high quality appearance, it is recommended you regularly use a dry or slightly-damp soft cloth to keep the exterior of your speakers free from dust, lint or dirt. To clean dust from the grille, use a vacuum with a brush attachment and gently brush the surface of the grille.

Features

Proprietary Aluminized Fiberglass Matrix cone woofers are the heart of the Destination Audio CS100 & CS100C speakers. This special material is stiff, lightweight, and has self-damping properties which helps provide a virtually uncolored audio reproduction. These woofers have a powerful magnet that gives them high excursion capabilities; this helps the CS100 & CS100C provide an extended dynamics and frequency response not typically found in speakers of their size. To avoid any interference with tube-type televisions and monitors, the CS100C is video shielded using additional opposing magnets and steel cups to cancel any stray magnetic fields.


High frequencies are handled by a high-quality nano-silk tweeter. This tweeter uses liquid cooling to allow for greater power handling. This allows the tweeter to last longer and provide accurate reproduction at the higher power output levels today's amplifier systems are capable of. The CS100C's tweeter's magnet is also shielded to prevent any stray magnetic fields from negatively affecting the speaker's environment.

Steep crossover network slopes are used to integrate the CS100 & CS100C's woofers and tweeters. The use of steep crossover slopes allows higher than average power handling, minimizes the audio interaction between the drivers, and maximizes the speaker's overall clarity by allowing each driver to specialize in its own respective frequency band. One component featured within the CS100 & CS100C's crossover networks is a polyswitch. A polyswitch, or current-limiting device, is used to prevent damage to the tweeter if the speaker is over-driven or fed a distorted audio signal. This device operates 900% faster than a fuse and self-resets when the volume level or amount of distortion is reduced.

The CS100 & CS100C enclosures have a narrow profile to minimize the impact the cabinet has on the audio signal. The speakers virtually disappear, leaving only a wide, deep sound stage with pinpoint imaging typical of much higher priced speakers. A special damping material is also used inside the cabinet to dampen the internal standing waves which helps these speakers provide a true-to-life experience.

Attaching Mounting Bracket

A mounting bracket and the necessary hardware are included with the CS100 to allow them to be mounted to a wall or speaker stand. Choose a suitable location for the speakers, and use four screws to mount each bracket to the surface of the chosen area. If mounting on drywall, use the four drywall wall anchors (included) to increase the sturdiness of the mount. First, use a pencil to mark the location of each of the four holes, and then use a Phillips head screwdriver to screw the drywall anchors into the drywall. Then place the bracket against the wall and use four screws (placing one in each drywall anchor) to fasten the bracket to the wall. Place the speaker against the bracket, lining-up the speaker's threaded insert against the hole in the bracket, and use the Attachment Knob to fasten the speaker to the bracket. Pay close attention to face the speaker in the desired direction before tightening the Attachment Knob.



System Setup

To obtain the best possible sound quality from your CS100 & CS100C speakers, it is important to place the speakers where they will sound best in your listening room. Your room will influence the balance, imaging and overall sonic quality of the system, so you may want to experiment with speaker placement to determine which location offers the best overall sound for each speaker. As a general guide, use the room layout diagram and the following descriptions when setting up a home theater system. Some speakers shown in the diagram may not always be applicable to your individual system.

Front Main Left and Right Speakers

As a suggested starting point for the front left and right main speakers, try to place your speakers about 15 inches away from the wall and 7 feet apart from each other. The distance from the listening position to each speaker should be

System Setup (continued)

close to the distance that separates the two main speakers (i.e.: a triangle). The Destination Audio CS100 & CS100C compact theater speakers can also be hung on a wall or placed in bookshelves to better match your décor. If this is how your system will be arranged, keep in mind the spacing comments above for best performance. Also, slightly angling the speakers inward towards the listening position may give a more spacious and realistic sound stage.

Center Channel Speaker

For optimal performance in surround sound applications, the center channel speaker (typically the CS100C) should be placed in the middle between the front left and right main speakers. Often this positioning dictates placing the center channel speaker either directly above or below a television or monitor. Since the CS100C compact theater speaker features video shielding, it may be placed in close proximity to any television without cause for concern. Also, the CS100C may be placed in either a horizontal (lying down) or vertical (standing) position.


Surround Channel Speakers

The surround channel speakers should be placed slightly above and behind, and/or to the sides of, the listening position. For best performance, try to keep the listening position centered between the surround channel speakers. You may want to experiment with angling the surround speakers either towards or away from the listening position (depending on your décor and your room's furnishings) to obtain better sound quality.

Subwoofer

Placement of the subwoofer will largely determine the quality, quantity, and extension of the bass frequencies in your listening room. Bass frequencies are reinforced by close room boundaries. Placing the subwoofer nearer to a corner will make the subwoofer sound louder and boost the very lowest frequencies. Placing the subwoofer away from a corner or walls will provide the least reinforcement, possibly making the bass sound subjectively thinner than if the subwoofer were closer to a wall or corner. A good starting point for subwoofer placement would be along a wall and up to 3 feet from the corner. You may want to experiment with subwoofer placement and the subwoofer amplifier controls to achieve the proper bass balance.

System Setup (continued)






NOTE: There are several different surround formats available. Dolby Pro-Logic, Pro-Logic II, Dolby Digital and DTS generally have a 5-speaker plus subwoofer setup. Dolby Digital EX and DTS ES add an additional center rear speaker. Some newer receivers also offer the use of 7 or more effects channels. Please consult your audio/video professional to determine which surround format and system is best for you and how many speakers you will require.

Attaching Speaker Wires

The CS100 & CS100C use spring-loaded speaker wire terminals to firmly hold either a pin connector or bare speaker wire. To obtain a better connection, it is important to slightly tug on the wires after they have been secured in the terminals. This will cause the small teeth inside the connectors to 'bite' into the wire. It is recommended that you use wire which is color-coded or marked on one side. If the distance is less than 50 feet long from the amplifier or receiver to the speaker, use 16-gauge or larger wire; if the distance is more than 50 feet long, use 14-gauge wire.

WARNING: Avoid routing the speaker wire near other electrical wires, and avoid nailing or stapling the speaker wire.

1. Separate the last 4 inches of the speaker wire conductors at each end of the wire.
2. Use a wire stripper to remove about ¼-inch of insulation from the end of each conductor.
3. Twist the ends of each conductor to secure loose strands.
4. Connect the positive wire to the red terminal on the back of the speaker by pressing down on the red positive (+) terminal's tab, inserting the end of the positive conductor, and releasing the tab.
5. Repeat this procedure to connect the negative conductor to the black negative (-) terminal.



Specifications

Model	CS100	CS100C
Frequency Response:	100Hz – 20Hz ±3dB	100Hz – 20Hz ±3dB
Sensitivity:	85dB (2.83V@1m)	88dB (2.83V@1m)
Recommended Power:	35-100 Watts	35-120 Watts
Woofers:	4" Aluminum Fiberglass Matrix	Dual 4" Aluminum Fiberglass Matrix
Tweeter:	1" Nano-Silk	1" Nano-Silk
Impedance:	8 Ohms	6 Ohms
Crossover Frequencies:	3000 Hz	3000 Hz
Viedo Shielding:	No	Yes
Dimensions:	Width: 5" Height: 7¼" Depth: 5"	Width: 14½" Height: 5" Depth: 6"
Grille:	Black	Black
Finish:	Black	Black
Weight:	3 lbs.	5.9 lbs.

Warranty

Your Destination Audio CS100 & CS100C speakers are covered by a limited warranty against defects in materials and workmanship for a period of five (5) years from the original date of purchase. This warranty is provided by the authorized Destination Audio dealer where the speaker was purchased. Warranty repair will be performed only when your purchase receipt is presented as proof of ownership and date of purchase. Defective parts will be repaired or replaced without charge by your dealer's store or the location designated by your dealer authorized to service Destination Audio products. Charges for unauthorized service and transportation cost are not reimbursable under this warranty. This warranty becomes void if the product has been damaged by alteration, misuse or neglect. Destination Audio assumes no liability for property damage or any other incidental or consequential damage whatsoever which may result from the failure of this product. Any and all warranties of merchantability and fitness implied by law are limited to the duration of this express warranty. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.



Audio Products That Complement Your Life.™

382 Marshall Way, Layton, Utah • USA • 84041

Toll Free: (800) 543-2205 • Fax: (801) 543-3300

www.destinationaudio.com